

# Model 460 Front Axle AL 0/C-1.3 33.61

730.3


Installation Survey	002
Sectional Views, Exploded Views	003
Special Tools	004
Oil Change	013
Removal and installation of front axle	030
Removal and installation of trailing arms	035
Removal and installation of wheel hub	220
Disassembly and reassembly of wheel hub	235
Removal and installation of joint housing and track rod	245
Disassembly and reassembly of joint housing	248
Removal and installation of constant velocity propeller shaft	250
Renewing radial sealing ring on drive pinion	280
Removal and installation of ring gear with differential	300
Removal, disassembly, reassembly and installation of drive pinion	305
Disassembly and reassembly of differential (with differential lock)	310
Disassembly and reassembly of differential (without differential lock)	315
Removal, disassembly, reassembly and installation of differential lock	330
Checking axle components	340

Installation Survey Front Axles 33.61

730.3

Designation	Unit reduction	Model	Installed in vehicle	
			Sales designation	Model
AL 0/1 C-1,3	44:9	730.300	300 GD / 4x4	460.312
				460.322
				460.323
				460.332
				460.333
				460.343
	48:9	730.301	230 G / 4x4	460.210
				460.220
				460.221
				460.230
				460.231
				460.241
	44:9	730.329	240 GD / 4x4	460.310
				460.320
				460.321
				460.330
				460.331
				460.341
	44:9	730.329	280 GE / 4x4	460.212
				460.222
				460.223
				460.232
				460.233
				460.243







**Layout of front axle**

- 1 Control arm
- 2 Trailing arm
- 3 Shock absorber
- 4 Coil spring


33.61 Sectional Views, Exploded Views




Front Axle up to Axle No. 7 023 946



Differential Lock up to Axle No. 7 023 946




**Front Axle AL 0/1 C – 1.3 Wheel Hub and Brake Components from Axle No. 7 023 947**




**Differential Lock from Axle No. 7 023 947**

## 33.61 Sectional Views, Exploded Views




Front Axle AL 0/1 C – 1.3 Drive Bevel Gear and Differential



### Axle components

25 Axle housing	103 Bolt	169 Kingpin
31 Washer	109 Housing	175 Bolt
37 Bolt	115 Track rod arm	181 Bolt
43 Gasket	121 Bolt	187 Nut
49 Cover	127 Shim	193 Front wheel hub
55 Bolt	133 Drive shaft	199 Sealing ring
61 Breather	139 Race	205 Taper roller bearing
67 Screw plug	143 Sleeve	217 Taper roller bearing
73 Closing cover	148 Compressor	223 Sealing ring
79 Taper roller bearing	152 Compressor	225 Sealing ring
85 Sealing ring	163 Nut	229 Spacer tube
91 Sealing ring holder	165 Lock	235 Sealing ring
97 Gasket	167 Wheel cap	550 Bracket


33.61 Sectional Views, Exploded Views



Drive components

- |                          |                          |
|--------------------------|--------------------------|
| 241 Shim                 | 311 Clamping sleeve      |
| 247 Taper roller bearing | 313 Repair set           |
| 253 Gear set             | 317 Taper roller bearing |
| 259 Bolt                 | 323 Shim                 |
| 265 Differential         | 329 Spacer bushing       |
| 271 Thrust washer        | 335 Taper roller bearing |
| 277 Side gear            | 341 Sealing ring         |
| 283 Differential         | 347 Flange               |
| 299 Thrust ring          | 353 Guard plate          |
| 305 Bolt                 | 359 Nut                  |






## Differential lock components

12 Axle housing  
24 Tube  
30 Slide piece  
36 Driver  
49 Sealing ring  
55 Cylinder  
61 Housing  
67 Shaft  
74 Shim  
83 Spring  
94 Spring

106 Washer  
117 Circlip  
126 Lever  
145 Bolt  
156 Cylinder  
167 Piston  
178 Sleeve  
189 Sealing ring  
210 Spring  
221 Gasket  
232 Bolt  
243 Switch


254 Sealing ring  
265 Gasket  
271 Washer  
278 Bolt  
290 Differential  
369 Shim  
429 Side gear  
451 Differential pinion  
472 Thrust ring  
493 Differential sider  
504 Drive shaft  
515 Propeller shaft  
526 Sealing ring

33.61 Sectional Views, Exploded Views



Brake components

- |                  |                 |
|------------------|-----------------|
| 16 Brake caliper | 100 Bolt        |
| 28 Bleeder valve | 112 Bolt        |
| 40 Dust cap      | 124 Guard plate |
| 52 Spring        | 136 Bolt        |
| 64 Stud          | 148 Brake disk  |
| 76 Repair set    | 160 Bolt        |
| 88 Repair set    |                 |



### Track rod components

400 Track  
430 Swivel joint  
436 Tensioning ring  
442 Sleeve  
448 Nut  
454 Split  
460 Clamp  
466 Clip  
472 Bolt  
478 Nut  
502 Shock absorber

504 Rubber ring  
506 Bush  
508 Washer  
514 Nut  
516 Bolt  
520 Bracket  
526 Bolt  
532 Nut  
538 Washer  
544 Nut

## Special Tools 33.61

730.3

Designation	Parts Number
Jaw wrench	460 589 00 07 00
Hexagon socket waf 14	001 589 61 09 10
Mandrel	305 589 00 15 00
Mandrel	312 589 05 15 00
Mandrel	343 589 03 15 00
Mandrel	352 589 04 15 00
Mandrel	360 589 00 15 00
Mandrel	363 589 04 15 00
Mandrel	385 589 03 15 00
Mandrel	387 589 04 15 00
Mandrel	395 589 02 15 00
Mandrel	460 589 11 15 00
Mandrel	460 589 12 15 00
Mandrel	460 589 15 15 00
Torquemeter	001 589 49 21 00
Dial gauge	001 589 53 21 00
Measuring instrument	363 589 02 21 00
Adjusting instrument	601 589 00 21 00
Measuring plate	601 589 00 23 00
Measuring piece	601 589 01 23 00
Retaining wrench	366 589 00 31 00
Spring tensioner	381 589 00 31 00

## 33.61 Special Tools


Designation	Parts Number
Retaining wrench	460 589 01 31 00
Spreading device	601 589 00 31 00
Internal extractor	000 589 29 33 00
Puller	000 589 31 33 00
Counter support	000 589 34 33 00
Puller	000 589 89 33 00
Puller	001 589 19 33 00
Puller	001 589 36 33 00
Extractor	001 589 43 33 00
Puller	116 589 22 33 00
Puller	123 589 08 33 00
Puller	186 589 10 33 00
Gripper	000 589 02 34 00
Retaining device	601 589 01 40 00
Piston resetting device	000 589 52 43 00
Plug-in mandrel	116 589 07 61 00
Mandrel	116 589 08 61 00
Split ring	460 589 01 63 00
Insert	601 589 01 63 00
Supporting bridge	601 589 02 63 00
Thrust piece	601 589 10 63 00
Spring balance	000 589 03 65 00

Oil filling capacity

Hypoid transmission fluid SAE 90 Sheet 235 of POL Specifications	1.6 l
---	-------

Special tools

Hexagon socket SW 14




001 589 61 09 10

Draining oil

- 1 Unscrew oil drain plug on bottom of axle housing with hexagon socket (SW 14).

**Note:** Drain oil when warm if possible.




Hexagon socket 001 589 61 09 10

R33-6737/1

Filling in oil

- 1 Screw drain plug into axle housing with special tool.
- 2 Fill oil into oil filler opening on cover. Oil level should be at lower edge of oil filler opening (1).
- 3 Screw in plug of oil filler opening with special tool.



1 oil level

R33-6738/1

Tightening torques in Nm (kpm)

Wheel mounting bolts	180 (18)
Steering rod on steering arm	65 (6.5)
Stabilizer on frame	70 (7)
Shock absorber at front axle	70 (7)
Transverse link at frame	186 (18.6)
Trailing arm at frame	120 (12)

Filling capacities

Hypoid transmission fluid SAE 90, Sheet 235 of POL Specifications	1.6 l
--	-------


Special tools

Puller



186 589 10 33 00


Torque wrench 80 – 400 Nm



000 589 10 99 01


Removing front axle

- 1 Place chocks in front of and behind rear wheels to secure vehicle.
- 2 Unscrew propeller shaft from clutch flange and secure propeller shaft to vehicle frame.
- 3 Unscrew both shock absorbers at front axle.




## 33.61 Removal and installation of front axle

**4** Loosen fastening bolt of transverse link from frame.




**5** Unscrew stabilizer from frame.




**6** Remove split pin of castle nut on steering arm and unscrew.

**7** Press steering rod off steering arm with special tool.




Puller 186 589 10 33 00

**8** Unscrew brake lines on left and right and seal with rubber caps.






**9** Unscrew line for differential lock control.  
Unscrew line for electric indicator lamp.



**10** Unscrew both trailing arms from frame, remove washers and rubber bearings.


**11** Jack up vehicle at front until the spiral springs can be removed, remove fastening bolt of transverse link completely and remove front axle to the front.




## Installing front axle

**1** Place front axle under vehicle in installation position. Fit spiral springs so that the end of the spring rests on the stop of the spring plate of the axle.

Screw in bolt at transverse link. Lower vehicle until the trailing arms can be inserted into the frame. Fit rubber bearings and washers and tighten nuts with 200 Nm.




**2** Tighten both shock absorbers with 70 Nm.




### 33.61 Removal and installation of front axle

3 Tighten fastening bolts of stabilizer with 90 Nm.




4 Tighten fastening bolt of transverse link with 200 Nm.



5 Bolt steering rod onto steering arm with 90–100 Nm and secure castle nut with split ring.

6 Bolt brake lines onto front axle.

**Note:** When fitting brake lines, ensure that the minimum distance is maintained between coil spring and brake hose. This minimum distance is 20 mm and must exist in all wheel positions.




7 Screw on cable for electric indicator lamp then screw on line for differential lock control and bleed until the indicator lamp on the instrument panel lights up to ensure that the lock is fully engaged.

8 Bolt clutch flange to propeller shaft.

9 After installing front axle, bleed brake.

10 Check and adjust oil level of front axle.



Removal and installation of trailing arms 33.61


730.3

Tightening torques in Nm (kpm)

Trailing arm at front axle	186 (18.6)
Trailing arm at frame	120 (12)

Special tools


Torque wrench 80 – 400 Nm




000 589 10 99 01

Removing trailing arms

1 Unscrew and remove trailing arms at frame and axle.




2 Press out bearing in a press using a suitable tube.



## 33.61 Removal and installation of trailing arms


### Installing trailing arms

**1** Press bearing into trailing arm in a press so that it projects equally on both sides.



**2** Insert trailing arm into frame and axle. Torque fastening bolts on frame to 120 Nm.

**3** Torque fastening bolts of trailing arm at axle to 186 Nm.



## Removing and installing wheel hub 33.61

730.3






### Settings

Wheel bearing play	0.02 – 0.04
--------------------	-------------

### Tightening torques in Nm

Both slotted nuts on wheel hub			200
Fixed caliper on joint housing	M 14 x 1.5	10.9	190 – 220
	M 16 x 1.5		250 – 280


### Special tools



### Removing


- 1 Unscrew fixed caliper and take off.

**Note:** On the righthand side use a (commercial-grade) socket shortened by 5 mm.




### 33.61 Removing and installing wheel hub

- 2 Pull wheel cap of the wheel hub using the special tool.
- 3 Unscrew the brake disc and take off.




Puller 116 589 22 33 00


**Note:** Widen hole 1 on retaining wrench 366 589 00 31 00 to 14.5 dia. Place brake disc on retaining wrench, align over hole 1 and bolt tight. Drill holes 2 and 3 with 14.5 dia. drill.



- 4 Release outer slotted nut.




- 5 Screw retaining wrench onto wheel hub, unscrew slotted nut with special tool.
- 6 Take off tab washer.
- 7 Unscrew inner slotted nut with special tool.



Retaining wrench 366 589 00 31 00  
Jaw wrench 460 589 00 07 00

## Removing and installing wheel hub 33.61

8 Take wheel hub off the axle, unscrew retaining wrench.




### Installing

1 Slip on wheel hub and screw on retaining wrench. Grease inner slotted nut on the contact face with hub and tighten with 200 Nm while at the same time turning the wheel hub.


Slacken the inner slotted nut far enough to achieve a clearance of 0.15–0.18 mm. Insert tab washer.

**Note:** This clearance may increase more if the thread tolerances are unfavourable.

Jaw wrench	460 589 00 07 00
Retaining wrench	366 589 00 31 00



2 Rub the outer slotted nut on the contact face to the tab washer with emery paper. Grease slotted nut and tighten with 200 Nm.




3 Fix shop-made holder (flat iron) to the suspension of the fixed caliper to enable the measuring instrument 363 589 02 21 00 to be safely mounted.

Check wheel bearing play by moving wheel hub back and forth.

Specified wheel bearing play 0.02–0.04 mm.


Retaining wrench	366 589 00 31 00
Dial gauge	001 589 53 21 00
Measuring instrument	363 589 02 21 00



## 33.61 Removing and installing wheel hub


4 After adjusting the wheel bearing play, secure the outer slotted nut by bending over the tab washer.

5 Fit brake disc and bolt tight.




6 Fit fixed caliper to the joint housing and tighten the M 14 x 1.5 fastening bolt with 190–220 Nm and the M 16 x 1.5 bolt with 250–280 Nm.

**Note:** On the righthand side, use a (commercial-grade) socket shortened by 5 mm.



7 Fit wheel cap using special tool.



Puller 116 589 22 33 00






Disassembly and reassembly of wheel hub 33.61

730.3

Filling capacities

Universal grease per wheel hub Sheet 267 of POL Specifications	50 g
---	------


Special tools

Mandrel	 S60 0280	343 589 03 15 00
Puller	 S60 0078	001 589 36 33 00
Grip	 S60 0083	000 589 02 34 00


Disassembly

1 Remove outer taper roller bearing from wheel hub with special tool and suitable thrust piece.

Puller 001 589 36 33 00  
Grip 000 589 02 34 00




2 Remove sealing ring holder with sealing ring.



### 33.61 Disassembly and reassembly of wheel hub


**Note:** From axle No. 7 000 561 a modified sealing ring holder has been fitted with a cellular polyurethane ring.

**3** Clean all parts and check for wear, replacing worn parts.




#### Reassembly

**1** Fit gasket into sealing ring holder




**Note:** From axle No. 7 000 561 a sealing ring of cellular polyurethane has been installed. The sealing ring holder has a different shape.

- 1 cellular polyurethane ring
- 2 sealing ring holder




**2** Coat sealing ring holder on the contact surface to wheel hub with Teroson Fluid T 307 or Dichtin 51 sealing compound and drive onto wheel hub.



## Disassembly and reassembly of wheel hub 33.61







**3** Drive outer wheel bearing onto wheel hub with special tool.

**4** Pack wheel hub with specified quantity of grease, ensuring that the bearing is well greased.



Mandrel 343 589 03 15 00

# Removal and installation of universal joint housing and track rod 33.61


		730.3
<b>Filling capacities</b>		
Universal grease per universal joint housing	800 g	
<b>Adjustment values</b>		
Preload of steering knuckle bearing	0.3 ± 0.05	
<b>Tightening torques in Nm (kpm)</b>		
Gasket holder on joint housing	20 – 25	(2 – 2.5)
Stop bolt (check nut)	15 – 20	(1.5 – 2)
Kingpin top on joint housing	110 – 125	(11 – 12.5)
Track or steering arm on joint housing	150 – 170	(15 – 17)
Track rod on track arm	90 – 100	(9 – 10)
Steering shock absorber bracket on axle housing	20 – 25	(2 – 2.5)
Guard plate on joint housing	20 – 25	(2 – 2.5)
<b>Special tools</b>		
Mandrel	395 589 02 15 00	
Torque wrench 20 – 100 Nm		000 589 64 21 00
Torque wrench	000 589 67 21 00	
Internal puller		000 589 29 33 00
Counter support		000 589 34 33 00
Puller		186 589 10 33 00
Torque wrench 80 – 400 Nm		000 589 10 99 01
Split ring		460 589 01 63 00




## 33.61 Removal and installation of universal joint housing and track rod

### Removal


- 1 Remove split pins of castle nuts at track rod.
- 2 Unscrew castle nuts.



- 3 Unscrew steering shock absorber from axle.




- 4 Press track rod off with special tool.




Puller 186 589 10 33 00

- 5 Remove wheel hub (33.61-220).
- 6 Unscrew guard plate from universal joint housing.




## Removal and installation of universal joint housing and track rod 33.61

- 7 Unscrew gasket holder from joint housing.



- 8 Unscrew kingpin at top and track arm or steering arm underneath and remove.


**Note:** Mark the shims and taper roller bearings on the kingpins so that they can be reinstalled in their original positions.



- 9 Remove joint housing with taper roller bearing at the bottom from the axle.




- 10 Remove gasket holder with gasket from axle.




## 33.61 Removal and installation of universal joint housing and track rod

11 Check gasket, renewing if necessary.




12 Remove taper roller bearing on top of kingpin and pull off taper roller bearing outer race with special tool.



Internal puller 000 589 29 33 00  
Counter support 000 589 34 33 00

13 Remove closing cover.


14 Clean all parts or check for wear.



### Installation

1 Fit closing cover.


2 Drive taper roller bearing outer race into axle with special tool. Insert taper roller bearing.




Installer 395 589 02 15 00

## Removal and installation of universal joint housing and track rod 33.61


**3** Fit gasket holder with gasket to axle so that the chamfer of the gasket agrees with the chamfer of the ball.



**Note:** A closed ball gasket is fitted from axle number 7 000 561. When installing, ensure that the chamfer points toward the ball.



**4** If it is necessary to measure the shims at the top and bottom of the universal joint housing because of fitting new parts, mount the special tool on the constant velocity propeller shaft.



1 Split ring 460 589 01 63 00

**5** Insert constant velocity propeller shaft into axle.


**6** Install joint housing without shims but with taper roller bearings. Torque slotted nut on wheel hub to 200 Nm. Torque fastening bolts of kingpin top and steering arm or track arm bottom to 10 Nm (100 kpcm).






33.61 Removal and installation of universal joint housing and track rod

1 Torque wrench 000 589 67 21 00



7 Measure the gap at top and bottom of universal joint housing with feeler gauge. Select for the **top** and **bottom** a 0.15 mm thinner shim to achieve a total preload of 0.3 mm.


**Note:** After measuring or determining the shims, remove complete universal joint housing with constant velocity propeller shaft and remove split ring (special tool).




8 Fit universal joint housing with taper roller bearing to bottom of axle and install track or steering arm and torque to 150–170 Nm.

**Note 1:** Install the shims and taper roller bearings in their original position or, if replacing parts, in the side determined previously.

**Note 2:** Connex dowel pins are installed in the universal joint housing from axle No. 7 004 272. When carrying out repairs, check these for damage and wear, renewing if necessary.




9 Fit kingpin at top and bolt tight with bracket. Tightening torque of bolts: 110–125 nm.




## Removal and installation of universal joint housing and track rod 33.61


**10** Bolt guard plate onto joint housing with 20–25 Nm.



**11** Bolt gasket holder onto joint housing with 20–25 Nm.




**Note 1:** Up to axle No. 7 000 560 bolt on gasket holder so that the parting surface points downward.



**Note 2:** From axle No. 7 000 561 a closed ball gasket with an inner and outer gasket holder and a paper gasket is installed. The paper gasket should be fitted between the outer gasket holder and the universal joint housing.


- 1 Outer gasket holder
- 2 Paper gasket
- 3 Ball gasket (closed)
- 4 Inner gasket holder




### 33.61 Removal and installation of universal joint housing and track rod

**12** From axle No. 7 000 561 the parting surface of the gasket holder must point upward. Conversion of old axles to the closed ball gasket is only possible if the new universal joint housing is fitted at the same time.

**13** Install wheel hub (33.61–220).




**Note:** From axle no. 7 000 561 the universal joint housing is fitted with a screwplug. When reassembling pack in 800 g universal grease per joint housing.




1 Opening for grease packing

**14** If a damaged rubber cup seal is detected on a used joint, the joint in question must be completely replaced.  
If the rubber capsleeve has been damaged when removing or installing the track rod, it is sufficient to renew the rubber seal.




**15** Fit track rod and torque castle nuts to 90–100 Nm. Secure castle nuts with split pin.



## Removal and installation of universal joint housing and track rod 33.61

**16** Bolt steering shock absorber to axle to 20–25 Nm.



Disassembly and reassembly of joint housing 33.61

730.3


Filling capacities

Universal grease per joint housing	800 g
------------------------------------	-------


Special tools

Mandrel		312 589 05 15 00
---------	--	------------------

Mandrel		352 589 04 15 00
---------	--	------------------

Mandrel		305 589 00 15 00
---------	---	------------------

Mandrel		360 589 00 15 00
---------	---	------------------

Mandrel		363 589 04 15 00
---------	---	------------------


Mandrel		387 589 04 15 00
---------	---	------------------

Puller		000 589 31 33 00
--------	---	------------------

Counter support		000 589 34 33 00
-----------------	---	------------------


Disassembly

- 1 Remove outer radial sealing ring from joint housing.




## 33.61 Disassembly and reassembly of joint housing

**Note:** From axle No. 7 000 561 the radial sealing ring is seated in the joint housing and should be removed using a mounting iron.




**2** Pull outer taper roller bearing outer race out of joint housing with special tool.



Puller 000 589 31 33 00  
Counter support 000 589 34 33 00

**3** Drive out inner wheel bearing and radial sealing ring using special tool.

**Note:** Mandrels Part No. 360 589 00 15 00 supplied up to mid-1980 have to be re-turned to an outer diameter of 0.4 mm less to enable them to also be used for the modified joint housing axle no. 7 000 561.




Mandrel 360 589 00 15 00

**4** Clean all parts and check for wear. Replace worn parts.

### Reassembly

**1** Drive in taper roller bearing outer race of inner wheel bearing with special tool.




Mandrel 352 589 04 15 00

## Disassembly and reassembly of joint housing 33.61

**2** Insert well-greased roller cage of inner wheel bearing in joint housing.


**3** Drive radial sealing ring into joint housing using special tool.

Mandrel 363 589 04 15 00 up to axle No. 7 000 560  
Mandrel 305 589 00 15 00 from axle No. 7 000 561



**4** Turn joint housing around and drive in taper roller bearing outer race of outer wheel bearing with special tool and insert well-greased taper roller bearing.


Mandrel 363 589 04 15 00



**5** Coat contact surface of radial sealing ring pointing toward joint housing with Teroson Fluid T 307 or Dichtin 51 sealing compound and drive in with special tool.

**6** Pack joint housing with specified quantity of grease.

Mandrel 312 589 05 15 00 up to axle No. 7 000 560  
Mandrel 387 589 04 15 00 from axle No. 7 000 561









**Note:** From axle No. 7 0004 272 the steering or track arm is additionally secured at the joint housing with a Connex dowel pin. During repairs, check this pin for damage, renewing if necessary.

## Removing and installing constant velocity joint shaft 33.61

### Tightening torques in Nm

Seal holder at joint housing			20 – 25
Track rod at track lever	M 16 x 1.5		120 – 140
Kingpin top at joint housing	M 12 x 1.5	10.9	110 – 125
	M 14 x 1.5	12.9	170 – 190
Track lever or steering arm at joint housing	M 12 x 1.5	12.9	150 – 170
	M 14 x 1.5	12.9	250 – 280


### Special tools



### Removing

**Note:** The constant velocity joint shaft may also be removed complete with wheel hub and joint housing, e. g. for changing the gear set.


- 1 Remove wheel hub (33.61-220/1).
- 2 Unscrew seal holder with ball seal.






## 33.61 Removing and installing constant velocity joint shaft

3 Unscrew fastening bolts for kingpin at top and take off brake hose holder.




4 Unscrew steering arm or track lever at bottom and remove.




5 Remove kingpin at top.

**Note:** Mark the shims of the kingpin and the steering arm or track lever and the taper roller bearings so that the original installation conditions exist when re-assembling.



6 Take off joint housing.

7 Pull out constant velocity joint shaft.




## Removing and installing constant velocity joint shaft 33.61

Up to Axle No. 7 023 946 refer to Notes 1 and 2.


**Note 1:** Constant velocity joint shaft with differential lock gearing: check O ring and cup seal and replace if necessary.

**Note 2:** Constant velocity joint shaft without differential gearing: check bearing race for scoring from running-in and remove from shaft if damaged. If a new bearing race has to be fitted to the shaft, it should be heated to 100–110 °C and shrink-fitted. The shaft seat must be free of oil and grease. The bearing race chamfer must be pointing to the short end of the shaft.



R33-6758

From Axle No. 7 023 947 the seal was repositioned into the supporting tube to the outside. Remove the bush and radial seal using special tool.




R33-60284

Puller 000 589 29 33 00  
Counter support 000 589 34 33 00


### Installing

**Note:** From Axle No. 7 023 947 the seal is in the outer part of the supporting tube, see detail X.



Z33-6229

Location of seal on outside, detail X.




Z33-6230


- 1 Drive shaft
- 2 Bush
- 3 Radial seal

# 33.61 Removing and installing constant velocity joint shaft

1 Install bush using suitable mandrel.




2 Knock in radial seal using special tool.



Mandrel 360 589 00 15 00

3 Introduce constant velocity joint shaft into the axle.


4 Mount joint housing.



5 Insert kingpin at top with shims and brake hose holder and tighten the fastening bolts with the specified tightening torque.

Thread	Strength	Tightening Torque (Nm)
M 12 x 1.5	10.9	110-125
M 14 x 1.5	12.9	170-190


**Note:** Install the shims as they were originally.



## Removing and installing constant velocity joint shaft 33.61


**6** Insert track lever or steering arm at bottom with shim and tighten the fastening bolts with the specified tightening torque.

Thread	Strength	Tightening Torque (Nm)
M 12 x 1.5	12.9	150–170
M 14 x 1.5	12.9	250–280



R33-6751


**7** Bolt the seal holder onto the joint housing with 20–25 Nm.



R33-6752


**Note 1:** Up to Axle No. 7 000 560 the seal holder is bolted on so that the parting face is pointing down.

**Note 2:** From Axle No. 7 000 561 a closed spherical seal with an inner and outer seal holder and a paper gasket is installed. The paper gasket is fitted between the outer seal holder and the joint housing. The parting face of the seal holder must now point up. It is not possible to convert older axles to the closed spherical seal unless the new joint housing is fitted at the same time.



R33-6753

**8** Install wheel and fixed caliper (33.61–220/3).








R33-6754

## Replacing radial seal on drive bevel gear 33.61

730.3

### Special tools




### Replacing radial seal


**1** It is essential to measure the friction torque of the entire axle using the special tool at the coupling flange (without wheels) before removing the coupling flange and seal.

Note the friction torque determined.

Jaw wrench 460 589 00 07 00  
Torquemeter 001 589 49 21 00




**2** Mark the slotted nut and drive bevel gear with scoring tool to indicate their position relative to each other.



### 33.61 Replacing radial seal on drive bevel gear


**3** Bolt special tool onto the clutch flange and unscrew the slotted nut with special tool.



Jaw wrench 460 589 00 07 00  
Retaining wrench 460 589 01 31 00

**4** Pull off clutch flange with special tool and check for signs of damage and scoring from running-in, replace coupling flange if necessary.


**Note:** On no account may the coupling flange be removed by hard blows from a hammer since this will result in damage to the bearings.



Puller 000 589 89 33 00


**5** Remove damaged radial seals and knock in new seal far enough with plastic hammer and special tool until the insert is resting against the axle housing.

**Note:** Before installing radial seals, pack space between dust and sealing lips with grease, lightly oil lips. Coat the outer circumference of the radial seals with Teroson Fluid T 307 or Dichtin 51 sealing compound. Only 1 radial seal is fitted up to Axle No. 7 001 890. It is not possible to convert older axles to 2 seals.



Mandrel 601 589 10 63 00 up to Axle No. 7 001 889  
Mandrel 460 589 15 15 00 from Axle No. 7 001 890


**6** Mount coupling flange on the drive bevel gear so that the notch on drive bevel gear is aligned with the notch of the coupling flange.



1 Notch on coupling flange  
2 Notch on drive bevel gear

## Renewing Radial Sealing Ring on Drive Pinion 33.61


**7** Screw on old slotted nut as far as the mark and measure the friction moment with special tool.



Claw wrench 460 589 00 07 00  
Torquemeter 001 589 49 21 00



**8** Remove old slotted nut. Fit new slotted nut, then slowly achieve specified friction moment by alternate tightening and measuring (rotating drive with torquemeter). The friction moment should exceed the value measured in Fig. 7 by 50 Ncm (5 kpcm).

**Note:** Check vertical and lateral runout of clutch flange with dial gauge at pilot for propeller shaft.  
Permissible vertical runout: 0.1 mm  
Permissible lateral runout: 0.1 mm



**9** Secure slotted nut.

**Note:** If the slotted nut is inadvertently overtightened and the friction moment increased beyond the permitted tolerance, the gear set must be completely disassembled in this case since the compression ring has been compressed during incorrect installation and has lost its effect and cannot be removed without disassembling the axle. In addition, it is not permitted to reinstall for the repair a slotted nut which has been previously used since this would also cause the drive bearing to fail prematurely.



- 1 Clutch flange
- 2 Slotted nut
- 3 Radial sealing ring
- 4 Radial sealing ring
- 5 Compression ring
- 6 Shim
- 7 O-ring

# Removal and Installation of Ring Gear with Differential 33.61

730.3







## Ajustment values

Backlash	0.1 – 0.15
----------	------------

## Tightening torques Nm (kpm)


Bearing bracket on axle housing M 10	65 – 75 (6.5 – 7.5)
Cover on axle housing M 8 10.9	40 – 50 (4 – 5)

## Specials tools

Torque wrench 20 – 100 Nm		000 589 64 21 00
Dial gauge		001 589 53 21 00
Measuring instrument		363 589 02 21 00
Expander		601 589 00 31 00
Retaining device		601 589 01 40 00
Spring balance		000 589 03 65 00

## Removal

- 1 Drain oil (33.61 – 013).
- 2 Unscrew cover and remove with gasket.
- 3 Remove constant velocity propeller shafts (33.61 – 250).






## 33.61 Removal and Installation of Ring Gear with Differential

4 Unscrew and remove bearing brackets.


**Note:** Mark the bearing brackets, shims and taper roller bearing outer races to enable them to be re-installed in their original positions.



5 Mount special tool on axle housing and tighten so that the differential can be removed.

**Note:** The clamping bolt of the expander must only be tightened to the point where the Belleville springs make full contact (refer to arrow).

Expander 601 589 00 31 00




### Installation

**Note:** If a new differential housing or different taper roller bearings are fitted, the preload of the differential housing bearings must be determined afresh.


1 Load differential housing with taper roller bearings and taper roller bearing outer races in a press to  $700 \pm 50$  kp.

Spring balance 000 589 03 65 00




2 Wind a cord several times around the differential housing and determine the tensile force with the special tool.

3 The tensile force at the spring balance determined in the press must also be reached in the axle housing. It can be modified by installing shims. Shims are available in sizes from 4.90 to 6.08 mm in steps of 0.02 mm.



## Removal and Installation of Ring Gear with Differential 33.61


**Note:** The expander must not be tightened when determining the friction moment in the axle housing.



1 Shims

**4** If no parts in the differential housing are replaced, preload the axle housing with expander 601 589 00 31 00, re-install the differential housing with shims, taper roller bearing outer races and bearing brackets in their original position.

**5** Torque the fastening bolts of the bearing brackets to 65–75 Nm.



**6** Fit special tool with dial gauge to axle housing so that feeler pin of the dial gauge is at right angles to the tooth face. Check backlash by moving the ring gear back and forward. Repeat this operation at at least four points around the circumference of the ring gear.



Measuring instrument 363 589 02 21 00  
Dial gauge 001 589 53 21 00


**Note:** The backlash is altered by fitting shims. If a thinner shim is fitted on one side, a shim thicker by the same amount must be installed on the opposite side of the differential housing to maintain the preload on the differential housing bearings.

## 33.61 Removal and Installation of Ring Gear with Differential

### Checking contact pattern

The manufacturing tolerances of the ring gear and drive pinion are such as to provide adequate adjustment of basic dimension and backlash for installation.

It is good practice, however, to check the contact pattern of the gear set. For this purpose, coat three ring gear teeth offset by 180° with India ink. Fit the special tool to the axle housing and press against ring gear, then turn forward and backward at drive pinion.




1 Retaining device 601 589 01 40 00

### Contact pattern at ring gear under load (ring gear braked)


#### Correct contact pattern

Such an ideal contact pattern can generally not be achieved in practice. The important aspect is, however, that the contact pattern does not at any point touch the outer edge of the tooth face.




#### Contact at tooth tip (incorrect)

**Remedy:** Slightly reduce the installation distance (basic dimension) of the drive pinion and simultaneously increase the installation distance of the ring gear slightly, i.e., so that the teeth of the ring gear do not engage so deeply into the teeth of the drive pinion to maintain the correct backlash.



#### Contact at base of tooth (incorrect)

**Remedy:** Slightly increase the installation distance (basic dimension) of the drive pinion and simultaneously reduce the installation distance of the ring gear slightly, i.e., so that the teeth of the ring gear engage more deeply into the teeth of the drive pinion to maintain the correct backlash.




## Removal and Installation of Ring Gear with Differential 33.61

**7** Coat both sides of gasket (Part No. 601 351 50 80) on cover with Terolan 2105 or Curilin sealing compound and bolt to axle housing with cover. Torque fastening bolts to 40–50 Nm.

**Note:** From axle No. 6 597 807 a second gasket with the Part No. 601 351 51 80 was approved. This gasket, make Reinzoflex, must not be fitted with sealing compound.

**8** Install constant velocity propeller shaft or complete assembly with joint housing and wheel hub (33.61–250).

**9** Fill in oil (33.61–013)



## Removing, disassembling, reassembling and installing drive bevel gear 33.61


















730.3

### Settings

Friction value of drive bevel gear  
with radial seal

2.5 – 3 Nm

### Special tools




## 33.61 Removing, disassembling, reassembling and installing drive bevel gear

### Removing and disassembling


- 1 Remove differential (33.61-300).
- 2 Bolt special tool onto the coupling flange and unscrew the slotted nut with special tool.

Retaining wrench 460 589 01 31 00  
Jaw wrench 460 589 00 07 00




- 3 Pull coupling flange off drive bevel gear using special tool.

Puller 000 589 89 33 00




- 4 Bolt special tool onto axle housing, knock out the drive bevel gear and take off together with compression ring.

1 Supporting bridge 601 589 02 63 00



- 5 Knock the taper roller bearing and the radial seal at the flange end out of the axle housing using the special tool.


Mandrel 343 589 03 15 00



## Removing, disassembling, reassembling and installing drive bevel gear 33.61

**6** Knock the bearing outer race of the taper roller bearing at the pinion end out of the axle housing with special tool and take off the spacer ring.


Mandrel 460 589 15 15 00  
Insert 601 589 01 63 00



**7** Pull the taper roller bearing off the drive bevel gear using special tool.

**8** Clean all parts and check for signs of wear.


Puller 001 589 19 33 00



### Reassembling and installing

**1** Knock the taper roller bearing onto the drive bevel gear with a suitable sleeve.


**Note:** If installing a different gear set or replacing the taper roller bearing at the pinion end, operations 2 to 6 below must be performed.



**2** Clamp measuring plate (1) into the vice and mount measuring instrument (2) with dial gauge (3) inserted. Mount measuring piece (4) onto measuring plate, create pretension of 8 mm at dial gauge and set to zero.

**Note:** Use the lower end of the measuring piece for setting.


1	Measuring plate	601 589 00 23 00
2	Measuring instrument	363 589 02 21 00
3	Dial gauge	001 589 53 21 00
4	Measuring piece	601 589 01 23 00




### 33.61 Removing, disassembling, reassembling and installing drive bevel gear

3 Mount the drive bevel gear on the measuring plate together with taper roller bearing and magnetic plate (5) (from special tool 601 589 01 23 00) and rotate several times. The difference of drive bevel gear with taper roller bearing to the measuring piece can then be noted.

- |   |                      |                  |
|---|----------------------|------------------|
| 1 | Measuring plate      | 601 589 00 23 00 |
| 2 | Measuring instrument | 363 589 02 21 00 |
| 3 | Dial gauge           | 001 589 53 21 00 |
| 5 | Magnetic plate       | 601 589 01 23 00 |




4 Set the adjusting instrument to the specified setting of 66 mm for checking. This is done by screwing the measuring pin (on circumference of adj. instrument) into the dial gauge, pressing the spacer firmly against the adjusting instrument. Create a pretension of 2 mm at the dial gauge and set the gauge to zero.



Adjusting instrument 601 589 00 21 00


5 Insert the measuring piece (1) into the axle housing, then introduce the adjusting instrument (2) and measure the production difference of the axle housing to the specified basic size of 66 mm.

**Note:** If there is a difference toward the centre of the crown gear (gauge indicates more than 2 mm), deduct this difference from the difference noted in step 3. If there is a difference toward the drive bevel gear, (gauge indicates less than 2 mm), add this difference to the difference noted in step 3.



- |   |                      |                  |
|---|----------------------|------------------|
| 1 | Measuring piece      | 601 589 01 23 00 |
| 2 | Adjusting instrument | 601 589 00 21 00 |

6 Determine the difference of the specified basic size of 66 mm to the basic size for the gear set being fitted (inscribed electrically on drive bevel gear).



- |   |                      |
|---|----------------------|
| A | Basic size to be set |
| B | Centre of crown gear |



## Removing, disassembling, reassembling and installing drive bevel gear 33.61

**Note:** If the difference is toward the crown gear (size less than 66 mm), again add the difference to the difference noted in step 3. If the difference is toward the drive bevel gear (size greater than 66 mm), deduct the difference from the difference noted in step 3. The size determined in this way is the thickness of the spacer ring. Spacer rings are available in sizes from 5.0 to 5.68 mm in 0.02 mm graduations.


**Example:** The difference measured from measuring piece to drive bevel gear with taper roller bearing and magnetic plate is 5.30 mm.

The production difference measured for the axle housing to the specified basic size of 66 mm is 0.12 mm toward the centre of crown gear. The inscribed basic size is 65.84 mm.

$5.30 - 0.12 + 0.16 = 5.34$  mm.

In this case the spacer ring fitted is 5.34 mm thick.

- 1 Coupling flange
- 2 Slotted nut
- 3 Radial seal
- 4 Radial seal
- 5 Compression ring
- 6 Spacer ring
- 7 O ring




233-6175

**7** Insert the calculated spacer ring in the axle housing so that the chamfer is pointing toward the coupling flange.

**8** Knock in the taper roller bearing outer race of the pinion end bearing with special tool.


**Note:** Since the housing is not machined flat, the bearing outer race must be driven in with a suitable copper or brass mandrel far enough for it to centre itself, then knocked in fully with mandrel 312 589 05 15 00.

Mandrel 312 589 05 15 00




**9** Knock in the taper roller bearing outer race of the flange end bearing with special tool.

Mandrel 385 589 03 15 00




## 33.61 Removing, disassembling, reassembling and installing drive bevel gear

**10** Insert drive bevel gear, bolt on special tool and position the spindle against drive bevel gear.




1 Supporting bridge 601 589 02 63 00

**11** Fit new compression ring onto drive bevel gear and knock in the outer taper roller bearing with a suitable sleeve.



**12** Fit O ring onto the drive bevel gear and push on until it rests against taper roller bearing.

**Note:** The O ring is fitted as standard only from Axle No. 7 001 890.



**13** Knock in both radial seals with plastic hammer and special tool far enough for the insert of the thrust piece to rest against the axle housing.

**Note:** Apply a thin coat of Teroson Fluid T 307 sealing compound to outer circumference of radial seals before fitting. Pack gap between dust and sealing lips with grease, lightly oil lips.


Up to Axle No. 7 001 890 only 1 radial seal is fitted. It is not possible to convert older axles to 2 radial seals.



Mandrel 601 589 10 63 00 up to Axle No. 7 001 889  
Mandrel 460 589 15 15 00 from Axle No. 7 001 890

## Removing, disassembling, reassembling and installing drive bevel gear 33.61


**14** Mount coupling flange on the drive bevel gear so that the notch on the bevel gear is aligned with the notch on the coupling flange.



- 1 Notch on coupling flange
- 2 Notch on drive bevel gear


**15** Bolt special tool onto coupling flange, screw on slotted nut and tighten firmly enough with special tool to reach the specified friction value.

**Note 1:** Check vertical and lateral runout of coupling flange with dial gauge at the pilot for universal shaft.  
Permissible vertical runout: 0.1 mm  
Permissible lateral runout: 0.1 mm



Retaining wrench 460 589 01 31 00  
Jaw wrench 460 589 00 07 00

**Note 2:** Check the friction value of the drive bevel gear with special tool. The friction value of the bevel gear must never be achieved by turning back the slotted nut. If the slotted nut has been over-tightened, a new compression ring must then always be fitted.




Torquemeter 001 589 49 21 00

**16** As a check, we recommend re-checking the basic size inscribed on the drive bevel gear, as described in steps 4 and 5. This requires the magnetic plate being mounted on the drive bevel gear.

**17** Secure the slotted nut by caulking the collar in the slot provided.

- 1 Coupling flange
- 2 Slotted nut
- 3 Radial seal
- 4 Radial seal
- 5 Compression ring
- 6 Spacer ring
- 7 O ring



Disassembly and Reassembly of Differential 33.61  
(with Differential Lock)

730.3

Adjustment values in Nm (kpm)

Friction moment when turning the complete differential	20 – 40 (2 – 4)
--	-----------------

Tightening torques in Nm (kpm)

Ring gear at differential housing	M 12 x 1	10.9	130 – 145	(13 – 14.5)
Cover at differential housing	M 8		30 – 35	(3 – 3.5)


Special tools

Mandrel



460 589 11 15 00

Torque wrench




000 589 27 21 00

Torque wrench 20 – 100 Nm



000 589 64 21 00

Puller




123 589 08 33 00

Mandrel



116 589 08 61 00


Torque wrench 80 – 400 Nm



000 589 10 99 01


Disassembly

1 Unscrew ring gear fastening bolts and remove ring gear by knocking downward around circumference with a soft mandrel.




### 33.61 Disassembly and Reassembly of Differential (with Differential Lock)


2 Unscrew fastening bolts of cover and remove cover.




3 Remove side gear with shim from cover.



4 Remove differential spider with differential pinions.




5 Remove differential pinions with spherical washers from spider.




## Disassembly and Reassembly of Differential (with Differential Lock) 33.61

**6** Remove side gear with washer from differential housing.



**7** Pull both taper roller bearings of differential housing or cover with special tool.


**8** Clean all parts and check for wear.



Puller 123 589 08 33 00

### Reassembly

**1** Drive both taper roller bearings onto differential housing or cover with special tool.



Mandrel 116 589 08 61 00

**2** Fit shims to both side gears so that the groove is pointing toward the side gear and insert the side gears in the differential housing or cover.


**3** Fit differential pinions with spherical washers to the differential spider and install this on the differential housing.






### 33.61 Disassembly and Reassembly of Differential (with Differential Lock)

- 4 Fit cover to differential housing so that the marks agree (same numbers).




- 5 Torque fastening bolts of cover to 30–35 Nm.




- 6 Check friction moment with special tool. Specified friction moment; 20–40 Nm.

**Note:** The friction moment can be altered by fitting different sizes of thrust washers. Thrust washers are available in sizes from 1.3–1.8 mm in steps of 0.1 mm.



Torque wrench 000 589 27 21 00  
Mandrel 460 589 11 15 00

- 7 Fit ring gear to differential housing and torque fastening bolts to 130–145 Nm.



# Disassembly and Reassembly of Differential 33.61 (without Differential Lock)

730.3

## Adjustment values in Nm (kpm)

Friction moment when turning complete differential	20 – 40 (2 – 4)
--	-----------------

## Tightening torque in Nm (kpm)

Ring gear at differential housing	130 – 145 (13 – 14,5)
-----------------------------------	-----------------------

## Special tools

Mandrel		460 589 11 15 00
---------	---	------------------

Torque wrench		000 589 27 21 00
---------------	--	------------------

Puller		123 589 08 33 00
--------	---	------------------


Installer		116 589 07 61 00
-----------	--	------------------

Mandrel		116 589 08 61 00
---------	--	------------------

Torque wrench 80 – 400 Nm		000 589 10 99 01
---------------------------	--	------------------

## Disassembly

To aid installation, we recommend fabricating a clamping device in the shop in accordance with the adjacent sketch.






### 33.61 Disassembly and Reassembly of Differential (without Differential Lock)

1 Unscrew the ring gear fastening bolts and remove ring gear by knocking down around the circumference with a soft hammer.


2 Clamp the differential housing with clamping device (self-made) in a vice.



3 Pull off both taper roller bearings with special tool.

4 Knock clamping sleeve for differential pin out of differential housing with a puller.

5 Press out differential pin and remove differential pinions, side gears, thrust washers and spherical washers.



1 Puller 123 589 08 33 00

**Note:** When removing the differential pinions, center the side gears with suitable mandrels. The differential pinions can be removed by turning the side gears.

6 Check components to determine whether they can be reused. Always replace differential pinions, thrust washers and spherical washers which have overheated or have score marks.


#### Reassembly

**Note:** Coat all sliding parts of the differential with special lubricant Molykote paste HTP or WHS LN 776 paste before installing.

1 Fit thrust washers to side gears and insert in differential housing.


2 Insert special tool (1) in side gears and fit both differential pinions with spherical washers on both sides and position in the correct installation position by turning the mandrels.

1 Installer 460 589 11 15 00




## Disassembly and Reassembly of Differential (without Differential Lock) 33.61

**3** Insert special tools in differential housing instead of differential pin for locating differential pinions and spherical washers.




**4** Check friction moment. The friction moment can be altered by installing thrust washers. Thrust washers are available in sizes of 1.3; 1.4; 1.5; 1.6 and 1.7 mm. Specified friction moment is 20–40 Nm (2–4 kpm).



1 Installer 460 589 11 15 00


**5** Knock differential pin into differential housing so that the dowel pin can be fitted.

**6** Drive in new dowel pin.



2 Installer 116 589 07 61 00

**7** Drive both taper roller bearings onto differential housing with special tool.




Mandrel 116 589 08 61 00

R 35-6642



### 33.61 Disassembly and Reassembly of Differential (without Differential Lock)

**8** Heat ring gear to 60° C and fit to differential housing, torquing the fastening bolts to 130–145 Nm.



Removal, Disassembly, Reassembly and Installation of Differential Lock




33.61

730.3

Tightening torques in Nm (kpm)


Lever on shaft	20 – 25 (2 – 2.5)
----------------	-------------------

Special tools


Mandrel		460 589 12 15 00
Torque wrench 20 – 100 Nm		000 589 64 21 00
Spring tensioner		381 589 00 31 00

Removal and disassembly

**Note:** Mark the installation position of the ZB selector cylinder relative to the axle housing before unscrewing the cylinder.




- 1 Unscrew differential lock from axle tube and remove with gasket.




### 33.61 Removal, Disassembly, Reassembly and Installation of Differential Lock


**2** Unscrew cylinder from housing and remove with gasket.



**3** Remove spiral spring and selector piston from cylinder.




**4** Check sealing ring and sleeve on selector piston, renewing if necessary.



- 1 Sleeve
- 2 Sealing ring


**5** Unscrew pushbutton switch for electric indicator lamp.

**6** Pretension springs, unscrew nut from shaft, remove lever and springs with shaft.




## Removing, disassembling, reassembling and installing differential lock 33.61

- 7 Take the large compression spring off the shaft.



- 8 Pretension the small compression spring on the shaft with special tool and remove the locking washer.




Spring tensioner 381 589 00 31 00

- 9 Remove constant velocity joint shaft (33.61-250).

- 10 Remove crown gear with differential (33.61-300).

- 11 Pull selector sleeve and selector tube slightly out of the axle. Take selector sleeve out at the side, then pull tube out fully.




- 12 Take polyamide rings off tube.

- 13 Remove the radial seals from the axle housing with assembly iron.

**Note:** From Axle No. 7 023 947 the radial seal was repositioned to the outside in the supporting tube.

- 14 Clean all parts and check for signs of wear. Replace worn parts.




1 Polyamide rings

## 33.61 Removing, disassembling, reassembling and installing differential lock

### Reassembling and installing


#### A Previous Version

(internal seal) up to Axle No. 7 023 946



#### B New Version

(external seal) from Axle No. 7 023 947






## Removing, disassembling, reassembling and installing differential lock 33.61

**1** Up to Axle No. 7 023 946 knock in radial seals with special tool.

**2** Fit polyamide rings onto selector tube, firstly introduce the selector tube slightly into the axle, then insert the selector sleeve from the side and push in both parts fully.

**Note:** When inserting the selector tube, ensure that the hole for the lever is pointing toward the opening of the differential lock.

Mandrel 460 589 12 15 00




**3** Pretension small compression spring and washer on shaft with special tool and fit the locking washer.

Spring tensioner 381 589 00 31 00




**4** Fit the large compression spring onto the shaft, push the shaft with springs into the housing and compress fully, fit lever and tighten nut with 20–25 Nm.



**5** Screw in pressure switch with electrical indicator with seal.

**6** Insert selector piston in cylinder, ensuring that the cup seal and sealing ring are fitted on the piston.




1 Seal



### 33.61 Removing, disassembling, reassembling and installing differential lock


**7** Insert compression spring into cylinder and screw cylinder with seal onto the housing.

- 1 Seal
- 2 Housing




**8** Introduce the selector tube with the polyamide rings fitted into the axle so that the hole for the lever is pointing toward the opening of the differential lock. Insert the selector sleeve from the side and push in the selector tube fully.

**Note:** The selector tube should be greased before being inserted.





**9** Push the selector tube fully toward the differential with a screwdriver so that the teeth are meshed.



**10** Introduce the shift cylinder pressurized with compressed air into the hole of selector tube, at the same time fit the seal and likewise push the shift cylinder toward the differential and screw tight.


**Note:** During assembly, ensure that no air escapes from the shift cylinder so that the differential lock is also fully engaged.





**Axle housing with suspension tubes**


Part No.	a	b	c	d
460 330 14 05	<u>64.274</u> 64.255	<u>88.870</u> 88.848	<u>88.958</u> 88.936	<u>70.046</u> 70.000



**Differential housing**


Part No.	a	b	c	d	e
460 353 01 01	<u>54.039</u> 54.013	<u>36.039</u> 36.000	<u>127.040</u> 127.015	<u>19.021</u> 19.000	157 $\pm$ 0.1

33.61 Checking Axle Components




Gear set

Part No.	No. of teeth Z2 : Z1	a	b	c
601 350 53 39	44 : 9	<u>127.025</u>	<u>41.312</u>	<u>30.191</u>
601 350 55 39	48 : 9	<u>127.000</u>	<u>41.301</u>	<u>30.180</u>



Wheel hub

Part No.	a	b	c
360 334 04 01	<u>70.000</u> 69.810	<u>46.033</u> 46.017	<u>40.991</u> 40.975



Universal joint housing

Part No.	a	b	c	d	e
460 337 02 06 li	<u>88.054</u>	<u>74.968</u>	<u>67.968</u>	<u>80.046</u>	<u>30.021</u>
460 337 03 06 re	<u>88.000</u>	<u>74.948</u>	<u>67.948</u>	<u>80.000</u>	<u>30.000</u>