

Installation instructions

Running boards

88.2

Type 463

These installation instructions describe the subsequent installation of the running boards (special steel) in combination with flared wheel arches.

Manufacturer: IAC, Mercedes-Benz part nos.:

463 850 01 07 and 463 850 02 07 (for wheelbase 2 400 mm)

or

463 850 03 07 and 463 850 04 07 (for wheelbase 2 850 mm)

Legal regulations

In the **Federal Republic of Germany** appropriate registration must be made in the vehicle documents. A copy of the enclosed certificate of non-objection and a confirmation made out by the Mercedes-Benz service station that the running boards have been installed according to the installation instructions must be presented to the TÜV/TÜA.

The installation instructions are divided into the following sections:

- A. Installation
- B. Parts


A. Installation

Note: The installation is the same on both sides.

- 1 Jack up vehicle.
- 2 Remove dummy plugs on sill on the inside and attach two brackets.

Note: With wheelbase 2850 mm three brackets are attached.


3 Lower vehicle.




Assemble running board

Note: The assembly is the same at the front and rear.


4 Attach clamps.



- 5 Insert bolts with washers for bracket.
- 6 Attach bracket.




front




rear

7 Mount spacer bushing.




- Attach end piece.
- 9 Make a paper template corresponding to the contour of the panel for the bore.
- 10 Drill bore dia. 9 mm into bottom of flared wheel arches.
- 11 Detach cover in fender at front and rear.



- 12 Attach running board, tighten at brackets and at the flared wheel arches using the inserted bolts (Pos. 5).
- 13 Attach cover in fender.
- 14 Attach panel on exhaust tail pipe.

Note: In 350 GD Turbo installed from start of production, rest phased-in.

Note: When jacking up with adapters for 2-post lifting platform, the running boards must be removed.



B. Set of parts: refer to Microfiche 1055, Group 99.